



Step #1 - Chimney Removal/Preparation



Existing Manhole with Adjusting Rings and Poor Vertical Alignment (Sectional View)

Legend



Chimney Removed (Sectional View)

- PRECAUTIONS MUST BE TAKEN TO PREVENT DEBRIS FROM ENTERING THE MANHOLE DURING THE ENTIRE REMOVAL AND RECONSTRUCTION PROCESS. THIS WILL PREVENT THE POSSIBILITY OF PLUGGED SEWERS, INTERRUPTIONS IN SEWAGE FLOW AND TIME REQUIRED TO REMOVE THE DEBRIS AFTER CONSTRUCTION.
- CUT AND REMOVE THE ASPHALT PAVEMENT, AROUND THE EXISTING MANHOLE CASTING, IN A CIRCULAR FASHION WITH A MINIMUM DIAMETER OF 54" AND CENTERED ABOUT THE CASTING. DISPOSE OF THE ASPHALT.
- REMOVE THE CASTING (MANHOLE RIM AND COVER) FROM THE TOP OF THE MANHOLE OR MANHOLE ADJUSTING RING(S). INSPECT THE RIM AND COVER FOR DEFECTS. IF DEFECTS ARE PRESENT, REPLACE WITH NEW RIM/COVER AS NEEDED. IF DEFECTS ARE NOT PRESENT, CLEAN & RETAIN FOR USE IN RECONSTRUCTION.
- REMOVE ALL ADJUSTING RINGS TO THE TOP OF THE CONCRETE CONE. DISPOSE OF THIS MATERIAL
- REMOVE ALL AGGREGATE AROUND THE MANHOLE THAT HAS BEEN EXPOSED BY THE ASPHALT REMOVAL AND DISPOSE OF THIS AGGREGATE. THE AGGREGATE MUST BE REMOVED TO A MINIMUM OF 3" BELOW THE LEVEL OF THE TOP OF THE CONCRETE CONE.
- CLEAN AND INSPECT THE TOP SURFACE OF THE CONCRETE CONE. THE SURFACE SHOULD BE SMOOTH AND FREE OF BUMPS AND PITS THAT MAY PREVENT A GOOD WATER TIGHT SEAL. GRIND THE SURFACE AS NEEDED TO REMOVE PROTRUSIONS. UTILIZE COMPRESSED AIR TO BLOW DUST AND DEBRIS FROM THE SURFACE AFTER GRINDING. CLEAN THE SURFACE WITH ACETONE. UTILIZE A HYDRAULIC CEMENT, ACCORDING TO MANUFACTURERS RECOMMENDATIONS, TO FILL IN DEPRESSIONS.

VILLAGE OF

ADA

CHOICE ONE

ENGINEERING

REVISIONS:

DATE

APPROVED:
OCT. 2008

PAGE No.

500-7

MANHOLE CHIMNEY RECONSTRUCTION

PAGE 1 OF 3