


TRACER WIRE NOTES

- A.** FOR OPEN CUT CONSTRUCTION TRACER WIRE SHALL BE COPPERHEAD HS REINFORCED TRACER WIRE MANUFACTURED BY COPPERHEAD INDUSTRIES, LLC. BLUE FOR WATER. GREEN FOR SANITARY.

FOR DIRECTIONAL DRILL CONSTRUCTION TRACER WIRE SHALL BE COPPERHEAD SOLOSHOT REINFORCED TRACER WIRE MANUFACTURED BY COPPERHEAD INDUSTRIES, LLC. BLUE FOR WATER. GREEN FOR SANITARY.
- B.** TRACER WIRE MUST BE RUN ON TOP OF THE PIPE CONTINUOUSLY FOR THE FULL LENGTH OF THE PIPE.
- C.** TRACER WIRE MUST BE RAN AND ATTACHED TO ALL WATER MAIN AND SERVICE LINES. TRACER WIRE SHALL BE TERMINATED AT WATCH VALVE BOXES, CURB BOXES, METER PITS, OR AS DIRECTED BY THE VILLAGE.
- D.** TRACER WIRE THAT MUST BE SPLICED SHALL USE SNAKEBITE TRACER WIRE CONNECTORS MANUFACTURED BY COPPERHEAD INDUSTRIES, LLC.
- E.** ALL MATERIAL, LABOR, EQUIPMENT NEEDED FOR THE INSTALLATION OF THE TRACER WIRE SHALL BE INCIDENTAL TO PIPE INSTALLATION.
- F.** DEPENDING ON CIRCUMSTANCES OF A SPECIFIC INSTALLATION, THE VILLAGE MAY ALSO REQUIRE THAT TRACER WIRE BE RUN TO CURB BOXES, OR FIRE HYDRANTS.

VILLAGE OF
ADA



TRACER WIRE FOR WATER MAIN PIPE DETAIL

REVISIONS:
JULY 2014

DATE
APPROVED:
JUNE 2007

PAGE No.

800-24